


Condensers for air-conditioning units

Suitable for: trucks and buses

replaces
Multibrand



Air-conditioning units are a safety factor because the driver's responsiveness and concentration levels drop considerably in overheated vehicle cabs. On the other hand, an optimally set air-conditioning unit ensures maximum driving safety with a pleasant working climate; even in high temperatures.

The task of an air-conditioning unit is to extract the heat from the ambient air and therefore regulate the temperature of the air. Furthermore, it draws moisture out of the air and therefore prevents windows steaming up.

The compressor vacuums the gaseous coolant from the evaporator and condenses it. From here, the coolant flows to the condenser which is situated in front of the vehicle cooler. In the condenser, the gas is cooled by the external air and is thereby liquefied. The heat extracted from the coolant is emitted into the ambient air at this point.

The dryer then collects the liquefied coolant and frees it of moisture and dirt. The coolant is expanded using the expansion valve and injected into the evaporator where it then condenses. Due to the low pressure and absorption of

ambient heat, the coolant is heated and therefore becomes gaseous. The cooled air then enters the interior of the vehicle and reduces the air temperature.

Further links

Similar articles from the product range

Note: Accessories are listed on the respective article detail page in the Partner Portal.

DT® condensers for air-conditioning units are distinguished by the following properties:

- High quality
- Excellent processing
- Optimum functionality
- Excellent heat conductivity
- Durability

We recommend regular maintenance of air-conditioning units.

Functional description of the individual components of the air-conditioning circulation:

1. Compressor
Transports the coolant through the air-conditioning system. It vacuums the coolant in a gaseous state in order to transfer it condensed under high pressure to the condenser.
2. Condenser
It has the task of cooling the heated, pressurised coolant. The heat is emitted in the ambient air through cooling fins. The pressure of the coolant reduces due to cooling and the state of the aggregate changes from gaseous to liquid.
3. Dryer
The dryer has the job of cleaning the coolant and extracting the moisture from it. The filter dryer only has a certain capacity for the collection of fluid. The dryer should therefore be exchanged during each repair or maintenance.

4. Expansion valve

The expansion valve takes the fluid coolant from the high-pressure to the low-pressure area. It controls the injected amount of coolant using the thermal load.

5. Evaporator

The pressurised coolant expands in the evaporator. It then changes from the fluid to the gaseous state. The created evaporation cold is emitted into the ambience and conducted into the interior of the vehicle using the large evaporator surface.

DT Spare Parts

The brand DT Spare Parts from Germany provides a complete range of vehicle parts and accessories with a 24 month guarantee – no matter whether for trucks, trailers, buses, transporters or further applications, e.g. cars, agricultural vehicles, construction vehicles, marine or industrial applications. The guaranteed brand quality is achieved through the consistent product optimisation and relentless quality assurance within the framework of the Diesel Technic Quality System (DTQS).

More info: www.dtqs.de