

Steering column

suitable for: Volvo

replaces
82394696



360° view

The steering column transfers the movement of the steering wheel to the steering gear. It consists of two shafts connected by a universal joint.

By connecting the steering wheel with the torsion bar of the steering gear, the rotational movement of the steering wheel is transferred almost without loss and without play. Furthermore, the steering column makes it possible for the steering wheel to be adjusted to the optimal setting of height, angle and distance to the driver.

Further links

Similar articles from the product range

Note: Accessories are listed on the respective article detail page in the Partner Portal.

Tips & tricks:

1. Lubricate the steering before assembly, because it is not supplied with lubrication.
2. Check the number of teeth in the fixture of steering which must be equal to the corresponding axis of the steering box.
3. Screw must be used with diameter that prevents the shaft output in the recess for locking.
4. The screw must be tightened until the shaft is fully clamped. Always use a new locking nut.

Request article or order in Partner Portal

DT Spare Parts

The brand DT Spare Parts from Germany provides a complete range of vehicle parts and accessories with a 24 month guarantee – no matter whether for trucks, trailers, buses, transporters or further applications, e.g. cars, agricultural vehicles, construction vehicles, marine or industrial applications. The guaranteed brand quality is achieved through the consistent product optimisation and relentless quality assurance within the framework of the Diesel Technic Quality System (DTQS).

More info: www.dtqs.de