

## Steering column switch, black

Suitable for: MAN, VW



Two indicators on each side, one at the front and one at the rear, are stipulated for trucks and buses. When used, these must illuminate with a frequency of 1.5 Hz ( $\pm$  0.5 Hz) = 90 x per minute ( $\pm$  30 x) on both sides simultaneously. The indicators are operated with a steering column switch on the steering column. The indicator switches automatically return to the original position, i.e. when steering out of the bend, the switches are automatically returned to the neutral position which means that the indicator is switched off.

The switch is returned to the original position with a tappet on the steering column which triggers a little lever on the indicator switch and causes it to return using spring force. When this happens, a switch is opened and the connection to the electronic control device (indicator unit) is interrupted and the process is ended.

The steering column switch can also be used to operate the horn, the high and low beams with headlight flashers, the windscreen wipers with two speeds, intermittent wiping and the windscreen wiper and wash system.

1/2 dt-spareparts.com

DT Spare Parts steering column switches are characterised by the following characteristics:

- 1. Lever made of sturdy aluminium, steel tube or plastic with durable lever bearing due to the oversized bearing block.
- 2. The shape of the rivet head and the design of the rivet join that correspond with the regulations of joining techniques.
- 3. Micro-switches that are extremely suitable for switching both high and very low currents due to the construction with silver-plated contacts.
- construction with silver-plated contacts.

  4. Precisely fitted plastic base with professionally crimped plug connectors. The plug connectors are nickel-plated or silver-plated for low contact resistance and to protect against oxidisation.
- or silver-plated for low contact resistance and to protect against oxidisation.

  5. The highly flexible halogen-free cables are designed with a 0.5 1.5 mm<sup>2</sup> oversized cable diameter according to the electrical load, in order to quarantee optimum operational safety.
- to the electrical load, in order to guarantee optimum operational safety.

  6. Extremely strong solder joins with the exclusive use of leadfree solder. Only tin, silver or copper alloys are used in order to fulfil the specifications of the RoHS directive 2002/95/EC (RoHS = Restriction of hazardous substances). A soldering flux is used in order to prevent exidation around the soldered area.
- substances). A soldering flux is used in order to prevent oxidation around the soldered area.

  7. The use of high-quality printed circuit boards made of glass fibre reinforced epoxy resin instead of lower quality phenol resin/paper boards. The use of smaller sized SMD components (Surface Mounted Device) allow automatic production in order to aim for improved reliability of the product.

## Hints & tips:

Before you replace the steering column switch, make sure that the earth and cable connections as well as the fuses are in perfect condition and that these are not the real cause of the fault.

Request article or order in Partner Portal

## **DT Spare Parts**

The brand DT Spare Parts from Germany provides a complete range of vehicle parts and accessories with a 24 month guarantee — no matter whether for trucks, trailers, buses, transporters or further applications, e.g. cars, agricultural vehicles, construction vehicles, marine or industrial applications. The guaranteed brand quality is achieved through the consistent product optimisation and relentless quality assurance within the framework of the Diesel Technic Quality System (DTQS).

More info: www.dtgs.de

2/2 dt-spareparts.com